



ES Manual de Instrucciones

EN Instructions Manual

IT Manuale di Istruzioni

UA Інструкція з Експлуатації

FR Manuel d'Instructions

PL Instrukcja Obsługi

BR Manual de Instruções


KZ Пайдаланушы Нұсқаулығы












EL Εγχειρίδιο Οδηγιών






RO Manual de Instrucțiuni

PT Manual de Instruções

RU Руководства по Эксплуатации



X4  064504	X2  062019 062020	X2  064501	X2  060210	X4  050412	X4  050130	X2  050207	X4  04394404
X2  014501*	X1  044507*	X2  01450219*	X2  01441331*	X2  042731	X2  044511*	X4  04450913	X4  041153*
X1  044512*	X2  044504*	X1  044513*	X4  04450504	X4  044510*	X4  04450100	X1  044429*	






014502* x2




04450913 x4



050207 x2



044512* x1



044513* x1



050130 x4



050412 x4

