














- F Notice de montage
- E Manual de instalación
- I Istruzioni di montaggio
- NL Montage-instructies




AQUA *Chrome*



MIX





DES1023B

A  x1	B  x1
C  x1	D  x1
E  x1	F  x1
	G  x2
H  x5	I  x3
	J  x2
K  x1	L  x4
	M  x3

● F Outillage nécessaire ● E Equipamiento necesario
● I Attrezzatura necessaria ● NL Benodigde gereedschap







MAX 50 mm

